

## SANI-PAC 15

### PEROXYACETIC ACID & HYDROGEN PEROXIDE SOLUTION

#### **APPLICATION**

**SANI-PAC 15** is an equilibrium mixture of peroxyacetic acid, hydrogen peroxide, and acetic acid, as well as proprietary ingredients and water. It controls sulfides, odor, slime, algae, and bacterial and fungal diseases in various agricultural water systems. It contains higher levels of hydrogen peroxide and less acetic acid than other competitive products, which results in superior performance.

**SANI-PAC 15** has a high oxidation potential and is very reactive. It exhibits excellent bactericidal and fungicidal activity against a wide range of microorganisms in cold or warm water.

#### **WATERBORNE PATHOGENS**

Legionella bacteria and other pathogens may be present in water systems. Application of a microbicide does not guarantee the absence of such pathogens, nor is it possible or reasonable to eliminate all risk of infection. Users should develop a comprehensive water management plan in accordance with ANSI/ASHRAE Standard 188, OSHA guidelines (OSHA Technical Manual Section III: Chapter 7), and other guidelines applicable to the specific facility/system. CH<sub>2</sub>O, Inc. recommends that testing for legionella bacteria be incorporated in the facility's water management plan.

#### **GENERAL USE DIRECTIONS**

**SANI-PAC 15** is recommended for use in agricultural or horticultural applications such as irrigation or drip water systems and greenhouses to control slime and algae. It can be used in soil and foliar applications to prevent/control bacterial and fungal diseases present in soil or on growing agricultural crops.

#### **SAFETY & HANDLING PROCEDURE**

**SANI-PAC 15** is a strong oxidizing agent. Any source of heat and combustibles such as paper, wood, or leather should be avoided. Temperatures above 86°F will degrade product, accelerate decomposition, and reduce shelf life. (Product is shelf-stable for up to one year when stored at room temperature and away from direct sunlight.) Drums must be stored in an upright position. Product should never be returned to the original container.

**SANI-PAC 15** is corrosive to skin, eyes, and mucous membranes in its concentrated form, and can be corrosive in use-dilutions.

Safety goggles or face shield and heavy rubber or vinyl gloves must be worn when handling the concentrated product. Impervious gloves and safety goggles must be worn when working with product dilutions.

#### **Control**

Daily testing is recommended to maintain proper control. Failure to monitor and maintain treatment levels can cause damage. In addition to monitoring and maintaining treatment levels, it is the customer's responsibility to ensure the product is fit for its intended application. Additional testing may be performed upon request.

#### **REGULATORY APPROVAL**

**SANI-PAC 15** is federally registered under the EPA registration number 63838-2-43553.

#### **PHYSICAL PROPERTIES**

Peroxyacetic acid (% wt.)	14.8-15.7
Hydrogen peroxide (% wt.)	21.5 – 22.5
Appearance	Colorless Liquid
Odor	Moderate, Pungent
Foam	None
Pounds per Gallon	9.3-9.8
pH of 10% Soln	<2

#### **Seller Warranty**

CH<sub>2</sub>O brand test reagent refills are available through your sales representative at no charge. Customers are required to confirm product compatibility via a control test for their specific application. CH<sub>2</sub>O recommends that you perform regular/daily testing to control chemical levels and cycles of concentration within established limits. Additional tests may be performed at your request. Test reports reflect conditions at the point when the analysis was performed. Results will change over time and with varying operating conditions.

Seller warrants that this product conforms to its chemical description and is reasonably fit for the purpose referred to in the product data sheet. Buyer is responsible to ensure that products and product dosages are appropriate for Buyer's particular application. Seller makes no other warranty or representation of any kind, express or implied, concerning the product, including NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OF THE GOODS FOR ANY OTHER PARTICULAR PURPOSE. No such warranties shall be implied by law and no agent of seller is authorized to alter this warranty in any way except in writing with a specific reference to this warranty. The exclusive remedy against seller shall be a claim for damages not to exceed the purchase price of the product, without regard to whether such a claim is based upon breach of warranty or tort. Jurisdiction for any issues arising from or relating to this product shall be in the courts of the State of Washington and the venue shall be Thurston County. Any controversy or claim arising out of or relating to this contract, or breach thereof, shall be settled by arbitration in accordance with the rules and procedures as stated in RCW 7.06 and shall be binding upon both parties without right to appeal, and judgment upon the award rendered by the Arbitrator(s) may be entered in any court having jurisdiction thereof.

Applies to all products sold by CH<sub>2</sub>O, Inc., and is hereby communicated to all of its customers as a condition of sale. Use of CH<sub>2</sub>O products is subject to the Standard Terms and Conditions as listed on CH<sub>2</sub>O, Inc.'s website at: [www.ch2o.com](http://www.ch2o.com).